



TILE	DESCRIPTION
	AIR SAMPLING INTAKLE GRILLE c/w
	TEMPERATURE/HUMIDITY SENSOR (FREE ISSUE)
	3 x 240V/13A ELECTRICAL SOCKETS
	2 x 20" NON-DICOM PACS VIEWER c/w COMPUTER
	LEXAN FOIL HOSEPROOF KEYBOARD
	ANALOGUE TIME OF DAY CLOCK
	DIGITAL ELAPSED TIME CLOCK
	ELAPSED TIME CLOCK START/STOP/RESET
	10" HMI TOUCHSCREEN c/w THE FOLLOWING
	i) DIGITAL TEMPERATURE/HUMIDITY INDICATORS
	ii) TEMPERATURE/HUMIDITY CONTROLLERS
	iii) 2 No. GENERAL LIGHTING CONTROLS AND DIGITAL DIMMING
	iv) MAIN OPERATING LIGHT ON/OFF
	v) SATELLITE OPERATING LIGHT ON/OFF
	vi) FULL MEDICAL GAS FAULT ALARM
	vii) FULL IPS/UPS FAULT ALARM
	viii) VENTILATION PLANT CONTROLS/ALARMS/INDICATORS
	ix) GENERAL POWER INDICATORS
	x) AGSS CONTROL SWITCHES/INDICATORS
	xi) DOOR INTERLOCK
	xii) "THEATRE IN USE" ON/OFF SWITCHES
	viii) ULTRA CLEAN VENTILATION (UCV) CONTROLS/INDICATORS

**CONSTRUCTION**

FRONT FASCIA, DOOR & TILES OF 14swg GRADE 304 STAINLESS STEEL EPOXY POWDER COATED WHITE.

1ST FIX BACK BOX OF 16swg ZINTEC MILD STEEL, EPOXY POWDER COATED WHITE.

**Starkstrom Ltd**  
 256 FIELD END ROAD  
 EASTCOTE, RUISLIP  
 MIDDLESEX, HA4 9UW  
 Telephone : +44 (0)208 8683732 Fax : +44 (0)208 8683736  
 Website : www.starkstrom.com e-mail : info@starkstrom.com

THIS DRAWING IS THE EXCLUSIVE PROPERTY OF BPG MEDICAL DESIGN LTD. AND MUST NOT BE COPIED OR REPRODUCED IN ANY WAY WITHOUT EXPRESS CONSENT IN WRITING. THE DRAWING IS TO BE USED FOR THE PURPOSE FOR WHICH IT IS SUPPLIED AND MUST BE RETURNED ON DEMAND. THE CONTENTS OF THE DRAWING MUST BE TREATED AS STRICTLY CONFIDENTIAL AND MUST NOT BE DISCLOSED TO ANY THIRD PARTY WITHOUT EXPRESS CONSENT IN WRITING.  
 COPYRIGHT BPG MEDICAL DESIGN LIMITED ©2010  
 GENERAL NOTES:  
 THE DRAWING CONFORMS TO BS68.  
 ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE STATED.  
 IF IN DOUBT ASK.  
 INDICATE ALL SHARP AND SWAMP EDGES.

MATERIAL:  
 SPECIFICATION:  
 FINISH:  
 SURFACE TEXTURE:  
 UNLESS OTHERWISE STATED.

DATE	MODIFICATION	SER.	ISSUE	DATE	MODIFICATION	SER.	ISSUE
01.12.09	FIRST ISSUE			10.02.10	PANEL DID INCLUDE TWIN X-RAY + 1 PACS	SJP	B
						SJP	A

SURGEONS' THEATRE CONTROL PANEL REF. 3W-FA-FM-11T-S				SCALE:
DRG No:	T-372-01	REVISION:	B	MKS
CONTRACT: GARTNAVAL HOSPITAL		ISSUED FOR: INFORMATION ONLY		SJP
				APPROVED:
				DATE: 10.02.10
				CONTROLLED OR SHOWN:
				JOB NUMBER: 04531